


PINE RAISED GARDEN BASE ASSEMBLY INSTRUCTIONS

Preparation before starting:

- Select a flat site with sufficient space for the proposed raised garden. There may be small variations in board length and thickness due to sawmill tolerance. You will need to consider this when “stacking” the boards as described.
- The optional liner can be fitted to the inside walls of the garden once assembled. The liner provides a helpful barrier between the tanalised timber and soils.

Assembly Instructions:

1. Place boards into position as per the plan below to create the initial shape (one board high only, with overlaps as shown with short end boards fitting inside the side boards 980mm width total)
2. Check that corners are square. Check diagonal measurement from corner to corner both ways, the diagonal measurement should be within 5mm (adjust if required)
3. Attach the stainless steel corner brackets with the screws provided to a single height board on the outside face of all corners, whilst keeping the base of the bracket 10mm above the base of the bottom board.
4. Stack the remaining boards in place – and place screws into all bracket holes
5. Install the **optional** internal wall liner. Drape the liner around the inside face of the garden, and use the nail-plates spaced at 300mm apart around the top edge. Back fill with soil/mix



Note:

- Over time some of the long length board gardens may require an additional timber stake to be placed midway along their length, especially if gardens are fully filled with heavy back-soil. The tanalised timber is durable but if you wish to further extend the timbers life you can paint or coat timber with tung oil.
- Spare boards, Corner brackets, Screws and Liners are held in stock at Redpath
- Corner brackets can be adjusted at any time before back-filling, so as to create a neat top board joint appearance.

Redpath Raised Garden with cloche fitted

